



USERS MANUAL & SAFETY GUIDE

Thoroughly read this manual before assembling or using scaffolding unit. Failure to do so can result in **injury or death.** Seriously... **read it.**

One Year Warranty

This product is guaranteed for one year against flaws in materials and craftsmanship

SAFETY GUIDE



Read Before Use

Thoroughly read this manual before assembling or using scaffolding unit.



Electrical Warning

Never use scaffolding unit in proximity to live electrical circuits or power lines.



Do Not Over Encumber

This shelf was designed for a maximum load capacity of 35 lb (15 kg). Never step or stand on this shelf.

Prior to Use

- ▶ Only use scaffolding while complying with local, state, and national guidelines and legislation. It is the user's responsibility to know and follow the rules.
- ▶ A competent person should manually inspect scaffolding prior to each use, ensuring all parts are present and in good condition
- ▶ Refrain from using scaffolding if you are unwell, taking medication, consuming alcohol, mind-altering drugs or experiencing any other condition that may impair your ability to work.
- ▶ If any part or scaffolding component is damaged, it should not be used. It should be removed immediately from the work area and replaced. This includes exposure to heat, acids, or otherwise corrosive materials, excessive loads, or improper treatment.
- ▶ Always double check all connections before using scaffolding to make certain they are properly secured. This includes locking casters prior to climbing.
- ▶ Always climb scaffolding methodically, centered on and as close as possible to the ladder frame. Maintain a constant firm grip while climbing scaffold. Always maintain three points of contact.
- ▶ Remove all tools, material, and equipment before moving scaffolding. Never move scaffold while a person is on unit. Be careful when moving unit to avoid tipping.
- ▶ Keep body centered inside structure of scaffolding when in use to avoid tipping.
- ▶ Whenever a fall of 72" or more may occur, guardrails and outriggers should be in use.
- ▶ Warranty does not apply to faults that may occur when used in conjunction with alternate brands or manufacturers.

Work Smart Tool Shelf

- ▶ Load capacity of tool shelf is 35 lb. and should not be exceeded.
- ▶ Tools and materials should always be secured when not in use to prevent occurrences of falling objects.
- ▶ Falling object prevention, such as safety nets and barricades, should be in use whenever instances of falling objects are possible.
- ▶ Tether tools and materials, when possible, to prevent occurrences of falling objects.
- ▶ Safety barricades should be in use around work area below scaffolding when working at height.

DO NOTS

- ▶ Never step or stand on tool shelf.
- ▶ Never use scaffold in windy conditions or during inclement weather.
- ▶ Never use scaffold on unlevel surfaces.
- ▶ Never attempt to repair any part of the scaffolding unit. If parts are compromised, they should be removed from use immediately. Manufacturer replacements are available.
- ▶ Do not use scaffolding in close proximity to live electrical circuits. Metal conducts electricity, and electrocution can occur.
- ▶ Never modify scaffolding in any way. Altering the scaffolding unit voids its warranty.






Thank you for reading this: Now might be a good time to take a short break! Luckily, our shelf tray has a built-in cup holder.






Always secure tools and materials so that instances of falling objects may not occur. Barricade the area beneath scaffolding when working at height. Never exceed rated load capacity of this tool shelf, 35 lb.

MOUNTING OPTIONS






A**Mounting Bracket on Guardrails****Outside****Inside**


Round fitting of mounting bracket fits snugly around round tubing of guardrail.

**B****Mounting Channels on Guardrails****Top-rail****Mid-rail**

Mounting channels on underside of shelf rest over guardrails, allowing movement by sliding along rails.

**C****Mounting Bracket on End Frames****Inside****Outside**

Square fitting of mounting bracket fits snugly around square tubing of frame.



ScaffoldMart

.com

Sales Office: 1705 South Evans St. | Greenville, NC 27834 | **Warehouse Address:** 1002 North Pitt St. | Greenville, NC 27834

Phone: (866) 900-0983 | **Fax:** (252) 756-3849